


Switch activate, Pre-recorded Sales Helper

Operating Instruction

| | |
|---|---|
|  | <p><u>Features</u></p> <p>The module can play back a pre-recorded message with a push Button</p> |
|---|---|

Operation step

1. Open the sound module battery door and put in 3 AA size 1.5V batteries.
2. Turn on the power switch
3. Press the switch and the pre-recorded message will be played back

Capabilites of VT710F-SW

Power : 3 pcs AA size 1.5V battery

Size : 82×60×38mm

| | | | |
|--|----------------|---------------|----------------|
| Part # | VT710F-SW-10 | VT710F-SW-20 | VT710F-SW-40 |
| Voice duration | 10 second | 20 second | 40 second |
| Battery Lifetime (3 pcs alkaline battery) | 8,000 playback | 4000 playback | 2,000 playback |